


Pal - 102



SPK1 - for connecting speaker in panel-1.

SPK2 - for connecting speaker in panel-2

MIC1 - for connecting microphone in panel-1.

MIC2 - for connecting microphone in panel-2

COM - for connecting the common for two panel

D1 - for connecting the Doorstrike in door/gate 1

D2 - for connecting the Doorstrike in door/gate 2

D COM - for connecting the common of both Doorstrikes.

LINE1 - input phone line

TEL1 - output to the telephones

N.O - input for operating by relay control (max:24V/DC/1A or 120V/AC/0.5A)

Jumpers : PUSH- Setting in motion a relay by option - during somebody call from the door intercom

OPEN- Setting in motion a relay by option - during opening the door by pressing (0).