


# Pal - 202



- B1** - for connecting the second switch in panel-1
- B2** - for connecting the second switch in panel-2
- SPK1** - for connecting speaker in panel-1.
- SPK2** - for connecting speaker in panel-2
- MIC1** - for connecting microphone in panel-1.
- MIC2** - for connecting microphone in panel-2
- COM** - for connecting the common for two panel
- D1** - for connecting the Doorstrike in door/gate 1
- D2** - for connecting the Doorstrike in door/gate 2
- D COM** - for connecting the common of both Doorstrike.
- LINE1** - input phone line 1
- LINE2** - input phone line 2
- TEL1** - output to the telephones of line 1
- TEL2** - output to the telephones of line 2
- N.O** - input for operating by relay control (max:24V/DC/1A or 120V/AC/0.5A)

**Jumpers** : PUSH- Setting in motion a relay by option - during somebody call from the door intercom  
 OPEN- Setting in motion a relay by option - during opening the door by pressing ( 0 ).