


Pal – 102 DRT



B1 – Connecting to buzzer in the intercom

SPK1 - Connecting to the microphone in the intercom

MIC1 - Connecting to the earphone in the intercom

COM - Connecting common of both panels.

SPK2 - Connecting speaker in panel-2

MIC2 - Connecting microphone in panel-2

D1 - for connecting the Doorstrike in door/gate 1

D2 - for connecting the Doorstrike in door/gate 2

D COM - for connecting the common of both Doorstrikes.

LINE1 - input phone line

TEL1 - output to the telephones