







Operating instruction - pal 102




Door opening





Call waiting





To initiate call to the door or gates panel 1



To initiate call to the door or gates panel 2



All the Phones will ring again for somebody else to pick up



Intercom on the same line