





## Operating instruction - pal 202





Door opening





Call waiting





To initiate call to the door or gates panel 1






To initiate call to the door or gates panel 2






Capturing call






All the Phones will ring again for somebody else to pick up



Transferring call to second line



Intercom between both lines



Intercom on the same line